



STARTER / GENERATOR MOUNTING

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	1012316	STARTER / GENERATOR	1
2	1015240-01	BRACKET, MOUNTING	1
3	1015241	BELT	1
4	1014289	PULLEY	1
5	1016883	BRACKET, ADJUSTING	1
6	0000705	SCREW, HEX HEAD CAP, 3/8 - 16 x 1 1/4	2
7	0000357	WASHER, LOCK, 3/8	2
8	0000706	NUT, HEX, 3/8 - 16	2
9	1015331	SCREW, HEX HEAD CAP, M8 x 1.25 x 25MM	2
10	0007174	WASHER, LOCK, 5/16	3
11	1016074	SCREW, TORX HEAD, M8 x 1.25 x 18MM	1
12	1015932	BOLT, ROUND HEAD SQUARE NECK, 5/16 - 18 x 1	1
13	0001242	NUT, HEX, 5/16 - 18	1
14	1012384	WIRE ASSEMBLY, #6 BLACK	1
15	1015920	WIRE, GROUND	1
16	0007473	NUT, NYLON LOCK, 5/16 - 18	1
17	0001241	WASHER, FLAT, 5/16	1
18	0007173	SCREW, HEX HEAD CAP, 5/16 - 18 x 3/4	1

G

5